

# aspire®

## Spryte User Manual

Read this information leaflet fully before you start using this product as it contains important information. The notes below relate to when the device is filled with e-liquid that contains nicotine.

This product is intended for adult smokers. This product is not recommended for non-smokers, young people under the age of 18 years, pregnant or breast feeding women and those experiencing general ill health.



### Contents:

- 1\* Spryte device
- 2\* Extra O rings
- 2\* Coils (1\*1.8Ω & 1\*1.2Ω for Nic Salt)
- 1\* Silicone seal
- 1\* Micro USB Cable
- 1\* Warranty Card
- 1\* User Manual



### Specifications

- Spryte AIO Pod capacity: 3.5ml
- Spryte AIO coil is interchangeable with original CES BVC coils
- Built-in Battery Capacity: 650mAh
- Dimensions: 108\*26\*26mm
- Adjustable airflow
- Coil resistance: 1.8ohm
- Coil type: Nichrome
- Easy bottom fill
- Output wattage: 12W



- When using a new coil, let the pod stand for 5 minutes after filling so the cotton can be saturated with e-liquid before use.
- Do not let the pod become completely empty. Refill the pod to avoid dry burning or damage to the coil.

### Spryte AIO Filling

1. Pull and remove the pod from the main body of the Spryte AIO.
2. Invert the pod and lift the silicon seal.

3. Place the filling bottle/dropper into the pod filling hole.
4. Squeeze the filling bottle/dropper bulb to add your preferred e-liquid into the pod system.
5. Replace the silicone seal firmly.
6. Re-inset the pod into the power unit, and push down firmly until it 'clicks' into place.



### Spryte AIO Coil Installation

1. Pull and remove the pod from the main body of the Spryte AIO.
2. Invert the pod then unscrew and pull out the chimney unit.
3. Detach the atomizer from the airflow control ring and replace it with a new one.
4. Screw the chimney unit back to the pod system.

5. Re-insert the pod into the power unit, and push down firmly until it 'clicks' into place.

**Note:** To adjust the airflow of the Spryte AIO, please remove the pod and rotate the airflow control ring on bottom of the Spryte AIO pod.



### Instructions

- Pressing the fire button five times within two seconds will turn the device on or

off. The indicator lights will flash blue and red three times to indicate off or on.

- When the Spryte AIO is on, press the fire button the lights will indicate your Spryte AIO's current charge. When its current charge capacity is above 3.8 volts the indicator lights will be blue and red. When the charge is between 3.8 and 3.5 volts the lights will be blue only. When the charge drops below 3.5 volts the lights will then become red to remind you that it is time to charge your Spryte AIO.

### Protective Features

- Automatic Cutoff: The preset continuous fire time is 15 seconds, after 15 seconds of continuous firing, the LED lights will flash blue and red 10 times and the Spryte AIO will stop firing, it will fire again when the button is pressed.
- Short Circuit Protection: When the Spryte AIO detects a short, it will stop firing, and the LED lights will flash blue and red 3 times.
- Low Voltage Protection: When the battery level drops below 3.2V, the Spryte AIO will not function and the LED lights will flash 15 times.
- Overcharge Protection: When the Spryte AIO is fully charged, it will stop charging to prevent overcharging of your battery.

- Over heat protection: When the temperature of the control board is above 75 °C/167 °F, will on blue and red for 3 seconds to remind overheated and the Spryte AIO will cut off.

### Charging Instructions

- Charge via the Micro USB port. Maximum charge current can reach up to 1000mA.
- When the USB cable is attached the Spryte AIO indicator lights will flash blue and red three times. While charging the LED will indicate the Spryte's current charge status: 3.5 volts or less= red light; 3.5 to 3.8 volts= blue light; 3.8 volts and above =both blue and red lights. When the Spryte AIO is fully charged the LED will flash blue and red 20 times then remain off.

### IMPORTANT INFORMATION ABOUT USING NICOTINE CONTAINING E-LIQUIDS

Before using nicotine containing e-liquids the user should read the following information carefully.

### NICOTINE CONTAINING E-LIQUIDS:

Do not use if you are allergic to nicotine or any of the other ingredients contained within the e-liquid (see manufacturer's label for full details).

### WARNINGS AND PRECAUTIONS

Nicotine containing e-liquids are not recommended for:

- Non-smokers
- Young people under the age of 18 years;
- Pregnant or breast feeding women; as nicotine is known to cross the placenta and to be excreted in breast milk;
- Those experiencing general ill health; such as heart disease, stomach and duodenal ulcers, liver or kidney problems, long term throat disease or difficulty breathing due to bronchitis, emphysema or asthma;
- Those who have an overactive thyroid gland or have a pheochromocytoma (a tumour of the adrenal gland that can affect high blood pressure);
- Those who have diabetes, as nicotine may affect your blood sugar levels.
- Those taking the following medication;
  - Theophylline (to treat breathing problems)
  - Ropinirole (to treat restless leg syndrome)
  - Clozapine (to treat schizophrenia)

### POSSIBLE SIDE EFFECTS

If you inhale too much nicotine or use the product too much you may experience one or more of the following effects:

- Feeling faint;
- Nausea (feeling sick)

- Headache
  - Coughing
  - Irritation of the mouth or throat
  - Dizziness
  - Stomach discomfort
  - Hiccups
  - Nasal congestion
  - Vomiting (being sick)
  - Heart palpitations
  - Abnormal heart rate
- If you experience any of these side effects; including any possible side effects not listed in this leaflet, discontinue using the product, if the effect(s) continue after you stop use, consult your doctor or healthcare professional and bring this leaflet to their attention.

To learn more about your products and how to use, please visit: [www.aspirecig.com](http://www.aspirecig.com)

Shenzhen Eigate Technology Co., Ltd.  
Building 3, Xinhongtai Industrial Park,  
14 Jian'an Rd, Tangwei, Fuyong  
Town, Bao'an District, Shenzhen,  
China  
Tel: +86-755-81499783  
Email: [service@aspirecig.com](mailto:service@aspirecig.com)

Manufactured By Eigate MADE IN CHINA

